


NOTE: AIR AND VACUUM ASSEMBLY MUST BE INSTALLED AT HIGHEST POINT OF PRESSURE SEWER LINE. IF HIGHEST POINT FALLS IN A LOCATION WHERE ASSEMBLY CANNOT BE INSTALLED, PROVIDE ADDITIONAL DEPTH OF LINE TO CREATE HIGH POINT AT A LOCATION WHERE ASSEMBLY CAN BE INSTALLED.

# 1" & 2" AIR & VACUUM VALVE ASSEMBLY

PLAN #

	CITY OF LA CENTER APPROVED	REVISIONS:	DATE:	DRAWN:	DESIGNED:	SS-17
	<i>Bart Stapp, PE 7/23/09</i> CITY ENGINEER                      DATE					